

# Recliner Assembly Instructions

Your recliner comes packaged in one box.

**DO NOT** use any sharp objects to open plastic wrapped components as damage to product or components may result.

Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Estimated Assembly  
Time in Minutes


★ ☆ ☆  
<15 <45 60+

## Parts List

**A** 1 x Back



**B** 1 x Seat



\* **C** 2 x Front Legs



\* **D** 2 x Back Legs




\* **E** 4 x Plastic Washers



47mm

\* Replaceable Parts





## Assembly


### Step 1

**D**

Carefully cut underside packing straps using scissors.




### Step 2





Line up brackets. Push down hard on the back. Make sure bracket locks into place on both sides. There should be no gaps between the back and the seat.

### Step 3

#### OPTIONAL



Adjust each leg by inserting a washer (E) to make it even and level with the floor.



Your recliner style may differ from images. Care for your furniture by periodically tightening all legs.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

Customer Support: 866-238-0531  
Mon-Fri 8:00am - 4:30pm CST  
customerservice@furniturequestions.com